

NAVAL TECHNICAL TRAINING COMMAND

STUDENTS GUIDE

for

EA-6B I-CAP COMMUNICATIONS, NAVIGATION AND APS-130 RADAR ORGANIZATIONAL MAINTENANCE COURSE

SECTION I (INFORMATION SHEETS)

SECTION IV (DIAGRAMS)

C-102-3986



CNTT N4420D

NAVAL AIR MAINTENANCE TRAINING GROUP

For Training Purposes Only

NAVAL AIR MAINTENANCE TRAINING GROUP
STUDENT GUIDE
FOR
EA-6B I-CAP COMMUNICATIONS, NAVIGATION AND APS-130 RADAR
ORGANIZATIONAL MAINTENANCE COURSE
C-102-3986

SECTION I (INFORMATION SHEETS)

DATE: Se

(FOR TRAININ

TABLE OF CONTENTS

Table of Contents	i
Direct View Storage Tube (DVST) Operation	4.4.1-IS-1

EA-6B (ICAP) INTEGRATED NAVIGATION SYSTEM
MAINTENANCE ANALYST

INFORMATION SHEET 4.4.1-IS-1

DATE: September 1982

TITLE: DIRECT VIEW STORAGE TUBE (DVST) OPERATION

1. Components

a. DVST has five components

- (1) Writing gun
- (2) Deflection system
- (3) Flooding gun
- (4) Collimating system
- (5) Storage display system

b. Writing gun is comparable to the electron gun in a conventional CRT

- (1) Target is a storage display system instead of a viewing screen
- (2) Storage display system is charged by the video information contained in the write gun beam

c. Deflection system is a conventional magnetic deflection system

d. Flooding gun provides a continuous low energy beam

- (1) Collimating system ensures beam approaches the storage display system perpendicularly and with uniform density
- (2) Flood beam allowed to pass the storage display system on to the viewing screen and is proportional to the change on each storage element. The display pattern becomes a visual reproduction of the stored electric charge pattern

- (2) Electrode makes all electrons strike the storage surface at 90°

Storage display system consists of:

- (1) Storage surface: special phosphor on which information written by the electron beam
- (2) Collector electrode:
 - (1) Fine metallic mesh placed just behind the storage surface in flooding beam
 - (2) Provides a return path for secondary electrons
- (3) Backing electrode: mesh placed behind the storage surface which the storage surface is coated with phosphor
- (4) Aluminized viewing screen placed in front of the storage surface to give a bluish-green color

- d. Charge pattern on the storage surface controls the flood beam electrons that pass into the viewing screen field.
 - (1) The display pattern is a visual reproduction of the stored electric charge pattern.
 - (2) Control of the persistence is effected by the duration and frequency of the erase pulses to the backing electrode

3. Development of Operating Voltage

a. Viewing screen voltage

- (1) Generated by the High Voltage Power Supply (HVPS)
- (2) +10K VDC output is connected to the DVST viewing screen

b. Write gun is referenced to -2K VDC

- (1) Voltage is developed in the HVPS and routed to the High Voltage Coupler Assembly

c. Write gun control grid

- (1) A 5 KHz sine wave is generated by an oscillator in Sweep Loss Protect A2
 - (a) Amplitude of the sine wave is controlled by the PHD BRT Control on the DISPLAYS Control Panel
 - (b) Amplified sine wave is routed to a 5 KHz bias transformer rectifier in the High Voltage Coupler Assembly
- (2) 5 KHz bias transformer rectifier
 - (a) Transformer is a step-up device clamped to -2K VDC
 - (b) Rectifier is a voltage from -2K VDC to -1.8K of the 5 KHz input
- (3) Video from the Video Amplifier added to output from the grid G1

d. Write gun cathode

- (1) -2K VDC is reduced to approximately -1.8K VDC in the High Voltage Coupler Assembly and provided to the cathode/filament line as a baseline DVST cut-off
- (2) Composite intensity gate from the Intensity Gate Amplifier A3 is:
 - (a) Routed to the High Voltage Coupler Assembly
 - (b) Clamped to the baseline level
- (3) Clamped intensity gate is routed to the DVST cathode
 - (a) Negative pulses applied to the cathode decrease the negative grid-to-cathode voltage
 - (b) Decreased negative grid-to-cathode voltage permits electron flow and unblanks the DVST

NOTE: A DVST cut-off condition exists if either the PHD BRT control is at minimum or there is no intensity gate

e. Write gun filaments

- (1) 115V, 400 Hz, phase A is provided to a filament transformer in the High Voltage Coupler
- (2) 6.3 VAC secondary voltage is
 - (a) Clamped to the cathode potential to prevent arcing
 - (b) Routed to the DVST filaments

f. Write gun focus grid

- (1) -2K VDC within the High Voltage Coupler Assembly is routed to a zener diode/resistor voltage divider
- (2) DC level values between approximately -1.4 and 1.7K VDC are:
 - (a) Available with a focus potentiometer in the divider network
 - (b) Routed to the DVST focus grid

- g. Flood gun filaments are provided with 6.3 VDC from the 6.3 VDC Power Supply A12
- h. Flood gun cathode is wired to ground potential in Sweep Loss Protect Assembly A2
- i. Flood gun control grid is provided with an adjustable -30 VDC to 0 VDC from the Sweep Loss Protector Assembly A2
- j. Flood gun collimating grid is provided with filtered 120 VDC from the Sweep Loss Protector A2

NAVAL AIR MAINTENANCE TRAINING GROUP

STUDENT GUIDE

FOR

EA-6B I-CAP COMMUNICATIONS, NAVIGATION AND APS-130 RADAR
ORGANIZATIONAL MAINTENANCE COURSE

C-102-3986

SECTION IV (DIAGRAMS)

DATE: September 1982

(FOR TRAINING PURPOSES ONLY)


TABLE OF CONTENTS


	<u>PAGE</u>
WSI-T-0014, Airspeed/Altimeter Pitot - Static System Block Diagram	1
WSI-T-0015, Automatic Flight Control System Block Diagram -----	2
WSI-T-0019, Airspeed/Altimeter Pitot-Static System Displays and Controls -----	3
WSI-T-0020, Automatic Flight Control System Display and Controls	4
WSI-T-0021, Tactical Jamming System (TJS) I-CAP Simplified Block Diagram -----	5
WSI-T-0022, Tail Fin POD Surveillance Antennas -----	6
WSI-T-0023, Tracker Jammer POD -----	7
WSI-T-0024, Receiver Control and Monitor Panels -----	8
WSI-T-0025, Video Display, IP-933/ALQ-99 (V) -----	9
WSI-T-0026, Digital Display Indicator IP-1226/A -----	10
WSI-T-0027, Digital Display Indicator Control C-9877/A -----	11
WSI-T-0028, Jammer POD Control C-8318B/ALQ-99(V) -----	12
WSI-T-0029, Master Control Panel C-9978/ALQ-99D -----	13
WSI-T-0030, Jammer Status Panel -----	14
WSI-T-0031, BDHI and BDHI Control Panel -----	15
WSI-T-0032, Digital Recorder Controls -----	16
WSI-T-0033, AN/ALQ-92 (I-CAP) Simplified Block Diagram -----	17
WSI-T-0034, AN/ALE-29A (I-CAP) Simplified Block Diagram -----	18
WSI-T-0035, AN/ALQ-126 (I-CAP) Simplified Block Diagram -----	19
WSI-T-0036, ALQ-92 Display and Control Panels -----	20
WSI-T-0037, AN/ALQ-92 Frequency Counter Panel -----	21
WSI-T-0038, ALE-29A Control Panels -----	22
WSI-T-0039, DECM Control Panel -----	23
WSI-T-0009, ARC-105 (HF) and ARC-175 (VHF) Control Locations -----	24
WSI-T-0004, AN/ARC-175 (VHF) Radio Set Block Diagram -----	25
NAV-C-0002, VHF System Interface -----	26
WSI-T-0008, AN/ARC-159 (UHF 1 & 2) Radio Set Displays and Controls	27
WSI-T-0002, AN/ARC-159 (UHF 1 & 2) Radio Set Block Diagram -----	28
NAV-C-0003, UHF System Interface -----	29
NAV-C-0004, ADF System Interface -----	30
NAV-T-0004, ADF Antenna Pattern and 155 Hz Signal -----	31
WSI-T-0010, TACAN ARN-84 and IFF APX-72 Displays and Controls -----	32
WSI-T-0006, TACAN ARN-84 Simplified Block Diagram -----	33
NAV-T-0005, TACAN Simplified Block Diagram -----	34
NAV-T-0006, TACAN Coarse Bearing Transmission - Reception -----	35
NAV-T-0007, TACAN Fine Bearing Transmission - Reception -----	36
NAV-T-0008, TACAN Composite Bearing Transmission - Reception -----	37
NAV-T-0009, AN/ARN-84(V) Converter/Receiver -----	38
NAV-T-0010, AN/ARN-84(V) TACAN Control Panel -----	39
NAV-T-0011, Horizontal Situation Indicator Block Diagram -----	40
NAV-T-0021, Cabin Dump Panel -----	41
NAV-T-0020, Transponder Control C-6280A(P) APX -----	42
NAV-T-0012, Normal IFF Interrogation and Reply Pulse Trains -----	43
NAV-T-0013, Special IFF Reply Codes -----	44
NAV-C-0005, TACAN Interface Diagram -----	45
WSI-T-0005, IFF APX-72 Simplified Block Diagram -----	46
NAV-C-0006, IFF Interface Diagram -----	47
WSI-T-0007, AN/AIC-14A Intercommunication Set Control Locations --	48
WSI-T-0001, AN/AIC-14A Intercommunication Set Block Diagram -----	49

TABLE OF CONTENTS


PAGE

WSI-T-0003, AN/ARC-105 (HF) Radio Set Block Diagram -----	50
WSI-T-0018, Radar Altimeter and Doppler Radar Displays and Controls-----	51
WSI-T-0013, Radar Altimeter and Doppler Radar Block Diagram-----	52
WSI-T-0017, Attitude-Heading Reference System Displays and Controls-----	53
WSI-T-0040, AN/ASW-25B Data link System Block Diagram-----	54
WSI-T-0041, AN/ARA-63 Approach Control System Block Diagram-----	55
WSI-T-0042, AN/APN-154B Radar Beacon System Block Diagram-----	56
WSI-T-0043, AN/ASN-54 Approach Power Compensator Block Diagram-----	57
WSI-T-0044, AN/ASW-25B Data Link System Controls and Displays-----	58
WSI-T-0045, AN/ARA-63 Approach Control System Control and Displays-----	59
WSI-T-0046, AN/APN-154B Radar Beacon System Control and Display-----	60
WSI-T-0047, AN/ASN-54 Approach Power Compensator Control and Display-----	61
WSI-C-0006, EA-6B (I-CAP) Automatic Carrier Landing System-----	62
NAV-T-0022, Simplified ACLS Block Diagram-----	63
NAV-T-0017, 5" Attitude Director Indicator ID-1329A-----	64
NAV-T-0018, 3" Attitude Director Indicator ID-1791A-----	65
WSI-T-0012, Attitude - Heading Reference System Block Diagram-----	66
NAV-C-0007, Attitude Director Indicators Interface Diagram-----	67
WSI-T-0048, Computer Control Indicator, C-9969/AYA-6B-----	68
NAV-T-0036, Direct View Radar Indicator (DVRI)-----	69
NAV-T-0037, Pilot's Horizontal Display (PHD)-----	70
NAV-T-0038, APS-130 Radar Control Panel-----	71
NAV-T-0039, Displays Control Panel-----	72
NAV-T-0027, AN/APS-130 Radar System Block Diagram-----	73
NAV-T-0028, DVRI Block Diagram-----	74
NAV-T-0029, PHD Block Diagram-----	75
NAV-T-0033, PRF Generator-----	76
NAV-T-0034, Mixed Range Markers Generator-----	77
NAV-T-0035, RSG Relative Bearing Servo-----	78
NAV-T-0030, Roll Electronics Amplifier-----	79
NAV-T-0031, Pitch Electronics Amplifier-----	80
NAV-T-0032, P/O Scan Electronics Amplifier-----	81
WSI-C-0001 R1 EA-6B (I-CAP) Equipment Location (COMM/NAV)-----	82
WSI-C-0003 R1 EA-6B (I-CAP) Pilot's Cockpit-----	83
WSI-C-0004 R3 EA-6B (I-CAP) FWD Cockpit (ECMO 1)-----	84
WSI-C-0002 EA-6B (I-CAP) Equipment Location (ECM)-----	85







AUTOMATIC FLIGHT CONTROL SYSTEM BLOCK DIAGRAM




AIRSPEED / ALTITUDE PITOT-STATIC SYSTEM DISPLAYS AND CONTROLS

EA-66
WSI-1-0015
1-CAP




MISC SYSTEM CONTROL PANEL
18A30



AUTO PILOT CONTROL PANEL
C-9788/ASW-41

EA-6B
WSI-T-0020
I-CAP

AUTOMATIC FLIGHT CONTROL SYSTEM DISPLAY AND CONTROLS




**TACTICAL JAMMING SYSTEM (TJS) I-CAP
SIMPLIFIED BLOCK DIAGRAM**

EA-6B




WSI-T-002
I-CAP

SECTION VIEW OF TAIL FIN FAIRING




EA-6B
WSI-T-0022
1-CAP

TAIL FIN POD SURVEILLANCE ANTENNAS




EA-6B
WS1-T-0023
I-CAP

TRACKER JAMMER POD




CONTROL, INDICATOR ID-2057/ALQ-99D



D-7839A/ALQ-99


MONITOR PANELS

EA-6B
WSI-T-0024




EA-66
WSI-1-0025
1-CAP

VIDEO DISPLAY, IP-933/ALQ-99(V)




DIGITAL DISPLAY INDICATOR IP-1226/A

EA-6B
WSI-T-0026




DIGITAL DISPLAY INDICAT



JAMMER POD CONTROL C-8318B/ALQ-99(V)

EA-6B
WS1-T-0028
I-CAP



MASTER CONTROL PANEL C-9978/ALQ-99D

EA-6B
WSI-T-0029
I-CAP

NAV ONLY	CMPTR 1A	ATT LIMIT	WINDS
FWD PWR	CMPTR CP	FREQ MEM	TAS/HDG
AFT PWR	DIS DATA	TRK LOSS	



JAMMER STATUS

STA 1	STA 2	STA 3	STA 4	STA 5
PWR LOSS	PWR LOSS	PWR LOSS	PWR LOSS	PWR LOSS
NOT RDY	NOT RDY	NOT RDY	NOT RDY	NOT RDY
MAN FREQ	MAN FREQ	MAN FREQ	MAN FREQ	MAN FREQ
MAN ANT	MAN ANT	MAN ANT	MAN ANT	MAN ANT
JAM 1	JAM 1	JAM 1	JAM 1	JAM 1
JAM 2	JAM 2	JAM 2	JAM 2	JAM 2

PWR LOSS	PWR LOSS	PWR LOSS	PWR LOSS	PWR LOSS
NOT RDY	NOT RDY	NOT RDY	NOT RDY	NOT RDY
MAN FREQ	MAN FREQ	MAN FREQ	MAN FREQ	MAN FREQ
MAN ANT	MAN ANT	MAN ANT	MAN ANT	MAN ANT
JAM 1	JAM 1	JAM 1	JAM 1	JAM 1
JAM 2	JAM 2	JAM 2	JAM 2	JAM 2


JAMMER STATUS PANEL

EA-6B
 WSI-T-0030
 I-CAP




BDHI AND BDHI CONTROL PANEL

EA-6B
WSI-T-0031
I-CAP



CONTROL INDICATOR
TAPE RELOADING
C-9495/ASH-30


LOCATED BY RECORDER
IN RIGHT FORWARD
EQUIPMENT BAY



DIGITAL RECORDER CONTROL C-9494/ASH-30

DIGITAL RECORDER CONTROLS


EA-6B
WS1-T-0032
I-CAP



17


EA-68
WSI-T-0033
I-CAP

I-92 (I-CAP) SIMPLIFIED BLOCK DIAGRAM




AN/ALE-29A (I-CAP) SIMPLIFIED BLOCK DIAGRAM

EA-6B
WSI-T-0034
I-CAP




EA-6B
WSI-T-0035
I-CAP

I-CAP) SIMPLIFIED BLOCK DIAGRAM




C-4379/ALQ-55



C-7778/ALQ-92

ALQ-92 DISPLAY AND CONTROL PANELS


EA-68
WSI-T-0036
I-CAP




FREQUENCY COUNTER CONTROL UNIT

AN/ALQ-92 FREQUENCY COUNTER PANEL

EA-6B
WSI-T-0037




CHAFF CONTROL PANEL C-7813/ALE-29



CHAFF DISPENSER PROGRAMMER PANEL, MX-7718/ALE-29A

ALE-29A CONTROL PANELS


EA-68
WSI-T-0038
I-CAP




ALQ-126 SYSTEM CONTROL PANEL (CFE)

DECM CONTROL PANEL


EA-6B
WSI-T-0039
I-CAP



HF RADIO SET CONTROL
C-4958/ARC-105




VHF RADIO SET CONTROL
ARC-175




ARC-105 (HF) AND ARC-175 (VHF) CONTROL LOCATIONS

EA-6B
WSI-T-0009
I-CAP




EA-6B
WSI-T-0004
I-CAP

75 (VHF) RADIO SET BLOCK DIAGRAM









EA-6B
WSI-T-0002
I-CAP

AN/ARC-159 (UHF 1 & 2) RADIO SET BLOCK DIAGRAM




**ADF ANTENNA PATTERN
AND 155Hz SIGNAL**


EA-68
NAV-T-0004
I-CAP




HORIZONTAL
SITUATION
INDICATOR




CAUTION LIGHTS PANEL



TACAN CONTROL
C-9054/ARN-84 (V)




TRANSPONDER SET CONTROL
C-6280(P)/APX



CABIN DUMP PANEL


EA-6B
WSI-T-0010
I-CAP

TACAN ARN-84 AND IFF APX-72 DISPLAYS AND CONTROLS




EA-6B
WSI-T-0006
1-CAP

B4 SIMPLIFIED BLOCK DIAGRAM




EA-68
NAVY-T-0005
I-CAP

TACAN SIMPLIFIED BLOCK DIAGRAM




TACAN COARSE BEARING TRANSMISSION




TACAN FINE BEARING TRANSMISSION-RECEPTION

EA-6B
NAV-T-0007
I-CAP




TACAN COMPOSITE BEARING TRANSMISSION-RECEPTION

EA-6B
NAV-T-0008
I-CAP




AN/ARN-84(V) CONVERTER / RECEIVER

EA-6B
NAV-T-0009
1-CAP




EA-6B
NAV-T-0010
I-CAP

AN/ARN-84 (V) TACAN CONTROL PANEL




EA-6B
NAV-T-0011
I-CAP

HORIZONTAL SITUATION INDICATOR BLOCK DIAGRAM




EA-68
NAV-T-0021
T-CAP

CABIN DUMP PANEL









EA-6B
NAV-T-0020
I-CAP

TRANSPONDER CONTROL C-6280A(P)APX




NORMAL IFF INTERROGATION AND REPLY PULSE TRAINS


EA-68
NAV-T-0012
I-CAP



SPECIAL IFF REPLY CODES




48




EA-68
WSI-T-0001
I-CAP

-14A INTERCOMMUNICATION SET BLOCK DIAGRAM




EA-6B
WSI-T-0003
(I-CAP)


AN/ARC-105 (HF) RADIO SET BLOCK DIAGRAM



FORWARD ADVISORY
LIGHTS




HEIGHT INDICATOR
ID-1760/APN-194(V)




DOPPLER RADAR CONTROL - INDICATOR
C-4418A/ APN-153(V)

RADAR ALTIMETER AND DOPPLER RADAR DISPLAYS AND CONTROLS

EA-6B
WSI-T-0018
I-CAP




RADAR ALTIMETER AND DOPPLER RADAR BLOCK DIAGRAM




EA-6B
WSI - T-0017
I-CAP


ATTITUDE-HEADING REFERENCE SYSTEM DISPLAYS AND CONTROLS



EA-6B
WSJ-T-0040
1 CAP


AN/ASW-25B DATA LINK SYSTEM BLOCK DIAGRAM






EA-6B
WSI-T-0042
I-CAP

AN/APN-154B RADAR BEACON SYSTEM BLOCK DIAGRAM




AN/ASN-54 APPROACH POWER COMPENSATOR BLOCK DIAGRAM

EA-6B
WSI-I-0043
I-CAP



EA-6B
WSI-T-0044
T-CAP


AN/ASW-25B DATA LINK SYSTEM CONTROLS AND DISPLAYS



EA-6B


WSI-T-0045
I-CAP

APPROACH CONTROL SYSTEM CONTROL AND DISPLAYS




EA-6B
WSI-I-0046
I-CAP

AN/APN-154B RADAR BEACON SYSTEM CONTROL AND DISPLAY




EA-6B
WSI-T-0047
I-CAP

APPROACH POWER COMPENSATOR CONTROL & DISPLAY




SIMPLIFIED ACLS BLOCK DIAGRAM




5" ATTITUDE DIRECTOR INDICATOR ID-1329A

EA-6B
NAV-T-0017




3" ATTITUDE DIRECTOR INDICATOR ID-1791A


EA-68
NAV-T-0018



ATTITUDE - HEADING REFERENCE SYSTEM BLOCK DIAGRAM


EA-6B -
WSI-T-0012
I-CAP






DIRECT VIEW RADAR INDICATOR (DVRI)

EA-6B
NAV T-0036




PILOT'S HORIZONTAL DISPLAY (PHD)

EA-6B
NAV T-0037




RADAR CONTROL PANEL




DISPLAYS CONTROL PANEL

EA-6B
NAV T-0039




AN/APS-130 RADAR SYSTEM BLOCK DIAGRAM




EA-6B
 NAV-T-0028
 I-CAP

DVRI BLOCK DIAGRAM




EA-6B
NAV-T-0029
1-CAP

PHD BLOCK DIAGRAM




EA-6B
NAV-T-0033
I-CAP

PRF GENERATOR




MIXED RANGE MARKERS GENERATOR

EA-6B
NAV-T-0034
I-CAP




EA-6B
NAV-T-0035
I-CAP

RSG RELATIVE BEARING SERVO



EA-6B
NAV-T-0030
1-CAP

- ELECTRONICS AMPLIFIER



PITCH ELECTRONICS AMPLIFIER

EA-6B
NAV-T-0031
I-CAP

